

458/7 and 432 fridge not chilling flow diagram

Note A: 432 fridge switching voltage is 240v referencing a 240v neutral
 57/8 fridge switching relay voltage is 24vdc referencing plug J57 pin 2 on the interface pcb

Note B: 457/8 If environmental temp warm adjust target temp
 432 check environmental temp and defrost settings

